

CMS ISDVR4-8-16HVN-L USER MANUAL

MENU

- Chapter 1 Software Instruction..... 2
- Chapter 2 Installation instruction 3
- Chapter 3 Introduction of basic functions 6
- Chapter 4 Monitor..... 8
- Chapter 5 System 10
- Chapter 6 Account..... 22
- Chapter 7 Local Log 24
- Chapter 8 Record 25
- Chapter 9 Advanced 28
- Appendix A Abbreviations..... 34
- Appendix B Main parameters 34

Chapter 1 Software Instruction

1.1 Summary

This is a Central Control Software with powerful function and Distributed Architecture, integrate many windows, users ,languages, bidirectional Talk, video conference, Classic of electronic map, alarm center, be compatible with Other extended products and single directly connected devices surveillance system as one.

This software is only for connecting DVR, the manual only describes the software, for specific equipment features, please refer to related product manuals.

1.2 Features

1.2.1 User and Authority management.

Support N level organization management, user management and authority setup.

1.2.2 Data interface technology adopted.

All dates adopt data interface technology, so it can support every database sizes very Flexibility, such as SQL, MYSQL, and XML data and so on.

1.2.3 Support EXCEL edit to add device.

The platform support the user adopt Excel to add and edit devices, it's very convenience for user to maintain quantities of devices, improve system's usability and greatly reduce many works for maintenance

1.2.4 Intelligent Video Transport Protocol.

Intelligent Video Transport Protocol can do Maximize the use of network bandwidth, especially on the condition of Front-end network bandwidth limited, when to assure system based on high quality Image in very low network bandwidth, it can work well.

1.2.5 Scalable distributed network architecture.

Support multi servers running Coordinated, Intelligent load balancing, Flexibility to add server and Enhance the system capacity Effectively on the condition of Integrity assurance.

1.2.6 Perfect video monitoring.

While real time monitoring, system support alarm, recording, auto monitoring record, playback and so on, it can exactly control each channel recording status.

1.2.7 Dynamic regulation decoding buffer.

Flexibility in adjusting the fluency/real-time of video images when real time monitoring which can meet different user's need.

1.2.8 Adopting shelf technology

Modular Development and flexibly assembled applications.

1.2.9 Central management.

Centralized management of data throughout the system and Forwarding of data to provide the perfect multi-user real-time monitoring program. Remote users can real time monitor, record and playback through network.

1.2.10 Easy operation

In access control, Users can easily control and set each monitor point through the system, it also could integrate E-map.

1.2.11 High integration level

The system integrates other related in formations, like Alarm and Voice etc...

1.2.12 High reliability

The system designs a special Fault tolerance measures to assure data Integrity and system running dependability.

1.2.13 Good scalability

The system designs for Service, has good Scalability and Adaptability to maximally protect user investment.

1.2.14 Support Network management and load balancing.

1.2.15 Support multi devices upgrade volume via network.

1.2.16 Support User DIY interface and multi languages.

1.2.17 Support 4 channels real time playback.

1.2.18 Support connecting multi devices and view many videos (real time monitoring and playback)

1.2.19 XML data storage

Chapter 2 Installation instruction

2.1 Environment request of running

2.1.1 Hardware.

CPU P4/2.0G

Graphics must support hardware scaling (such as ATI, TNT2 and PRO, but suggest ATI9800 or above, dual channels, Memory (over 128M)/128bit

Note: it needs good configuration for memory, graphics and CPU If many screens need to be decompressed.

Netcard: 100/1000M


2.1.2 Software.

This CMS can run under Vista, Win XP, Win2000, Win2003 and Win2007, it's not suggestion for windows 98.


Please close all Antivirus Software and firewall so that it can write running program correctly and completely in the control center before installing the software, or it will not search any devices.

2.2 Installation step


2.2.1 Find " CMS_Eng_V1.0.0.2.T.20110722.exe " in the CD and run it like below picture.




2.2.2 Click "Next", then go to the below picture.



2.2.3 Click "Next", then choose the available user for this shortcuts like below picture.



2.2.4 Click "Next" to start setup and end setup like below picture.




2.2.5 Click "Finish" to end the setup, at the time it will come up this icon in the desktop

Please follow Chapter 3, 4, 5 instructions to operate this software after finishing installation.



2.2.6 Login



The image shows a login window titled "DVR" with a close button in the top right corner. Below the title bar is a dark grey header with the text "CMS". The main area contains a "User Name" field with the text "super" entered, and a "Password" field which is empty. Below these fields are two checkboxes: "Save Password" and "Auto Login", both of which are unchecked. At the bottom of the form are two buttons: "Login" and "Cancel".

The default user name is super, and default password is blank (no need to enter). You can choose to save the password and auto login when next time you open the software.


After the loading is finished, the main menu will display.



Chapter 3 Introduction of basic functions

3.1 CMS Operation Main Menu

Double click the device name to login the device, and then right click to choose to view the video.



3.1.1 Device display area

In this area, you can preview live screens by device and super account administrator setting, click device name or channel group to change channels.

3.1.2 Operation area

You can preview live screens, and setup parameters when system configuration and video searching in this area.

3.1.3 Time

3.1.4 Video disk status area

It can display the rest disk spaces where video files store

3.1.5 PTZ

3.1.6 Operation log

It will display alarm and operation information when setup and operating.

3.1.7 Menu Area

Users could set single menu and sub-menu in this area, select relevant menus to operate video surveillance system in the control center.

Diagram 1 Menu Configuration

No.	First Menu	Second Menu	Third Menu	Function & Instruction	Operating right
1	Preview			Click preview button "Monitor" to choose a preview of the screen, touring & switching among all channels and snapshot pictures of the screen. Shut down/open preview menu	Admin/User
2	PTZ			Controlling the speed cameras to go up, down, left, right and stop by operating panel, adjusting speed, zoom, focus, iris and auto pan, preset and tour.	Admin/User
3	Color			Set brightness, contrast, saturation and hue for video screen	Admin/User
4	System	Device manager	Add zone	Add zone for all devices	Admin/User
			Add device	Add video surveillance devices	Admin/User
5			Modify	Modify device name, ip address, user name and password	Admin/User
6			Delete	Delete video surveillance devices	Admin/User
7		Local Config	Base config	Select disk, disk list and logs maintenance	Admin/User
8			Alarm setting	Enable audio activated by alarm	Admin/User
9		Account	Group	Add and delete users' operating rights	Admin
10			User	Add, delete and manage users: Set user name, password and operating rights of menu	Admin
11		Local Log		Search alarm log and operation log in set time area.	Admin/User
12		Record	Playback	Search record file and playback	Admin/User
13			Record Plan	Set record time for every day	Admin/User
14	Advance	Decoder	Set DVR and decoder	Admin/User	
15		Map	Using this map,it can visually show every cameras location and find current monitoring page directly	Admin/User	





Chapter 4 Monitor

In the menu area, click "Monitor", it will turn to preview screen.

Monitor functions: Preview, PTZ and video specification configuration.


4.1 Preview

Diagram 2 Functions and instructions of preview

No.	Button	Meanings
1		click it to preview full screen for every channel
2		click it to preview 4 screens
3		click it to preview 9 screens
4		click it to preview 16 screens
5		click it to preview 25 screens
6		click it to preview 36 screens
7		click to to preview 64 screens
8		click it to enter full screen interface

4.2 Right-click Menu

At operating area, user can do below operation by right-click:



Close window: close the current screen

Close all windows: close all the current screens

Audio: click it and hear the voices from preset screens

Local record: click it to record at current channel and save the record at the relevant disk.

Snapshot: Capture pictures from current channel at any time and save it to relevant disk.

Start talk: start the bi-direction talk.

Device config: click it and go to device configuration interface.



Color Setting: adjust the color setting of the video.

View Full: Enable full view mode.


4.3 PTZ Control

When speed cameras are connected with DVR, user can control it at this center, turn up, down, left and right, stop running, adjust turning speed, zoom, focus and iris, preset and tour configuration. When user enable touring function, the speed cameras will tour according to preset.


Function:

No.	Button	Meanings
1		 means "turn",  means "stop turning"
2		Drag this pole to adjust speed rate
3		Click + to zoom in; Click - to zoom out
4		Click + to focus in; Click - to focus out
5		Click + to iris it; Click - to iris out
7		Set a location for the preset, calls the preset points, PTZ automatically turns to the setting position, add, delete and config preset point
8		Multiple preset points connected tour lines, call touring between points, the PTZ run around on the line

4.4 Color

No.	Button	Meanings
1		Brightness
2		Contrast
3		Saturation
4		Hue

Picture 4-3 Color

Note: Click  to resume Initial values

Chapter 5 System

5.1 Device manager



5.1.1 Click **to add zone, see below:**

Zone

Zone

Up Zone

OK Cancel



5.1.2 Click **to add device, see below picture:**

NO.	IP Address	Port
<input type="checkbox"/> 1	192.168.1.227	34567
<input type="checkbox"/> 2	192.168.1.227	34567
<input type="checkbox"/> 3	192.168.1.227	34567
<input type="checkbox"/> 4	192.168.1.219	6001
<input type="checkbox"/> 5	192.168.1.219	6001
<input type="checkbox"/> 6	192.168.1.219	6001

IP Search EditDevice

Device Name 192.168.1.227

LoginType IP Address Domain SerialID

IP Address 192.168.1.227

Port 34567 User Name admin

Password Zone Test

OK Cancel

IP Search: You can click it to search out the device in the LAN automatically.

Edit Device: Click to edit the device information that you search out.

Device Name: You can enter any desired name of the device.

Login Type: It supports 3 kinds of login method: IP address, Domain, Serial ID.

Domain: Domain name by external network such as xxxx.3322.org; xxxx.dyndns.org; xxxx.oray.org etc...


IP Address: IP address

Port: TCP port

User Name: User name of the DVR

Password: Password of the DVR

Click "OK" after you have done above parameters, the device will display in the device area, see below picture, you can only double click to open the device.



Note: Choose only one of Domain name and IP address



5.1.3 Click to modify device, see below picture:

NO.	IP Address	Port

Device Name:

LoginType:
 IP Address
 Domain
 SerialID

IP Address:
 Port:
 User Name:

Password:
 Zone:

After finishing all the modifications, click "OK"

5.1.4 Delete device



Choose the devices which you want to delete, then click

Note: Please make sure the device is disconnected before modifying and deleting it.

5.2 Local Device

5.2.1 Base Config

See below picture:

Local Config

Base Config | Alarm Setting | DDNSConfig

Record Set

Overwrite Length 60 Min Alarm Record Length 10 Sec

Disk List

Storage	Total Size(MB)	Used Size(MB)	Free Size(MB)	Free Percent
<input type="checkbox"/> C:\	48030	21446	26584	% 55
<input type="checkbox"/> D:\	63805	28192	35613	% 55
<input type="checkbox"/> E:\	62103	50782	11321	% 18
<input type="checkbox"/> F:\	64503	39522	24981	% 38

Log Maintenance

Alarm log keep days 30 Show alarm log

Operation log keep days 30

Automatically connect with the last monitoring channel Automatically expand channel after connected

Picture DIR C:\Program Files\CMS\Picture

Record DIR C:\Program Files\CMS\Record

Save local record as AVI Run On Startup Auto Login

Sync time with PC

Never

Version Info

Video: 1.0.0.4 Net: 2.0.0.6

Decoder: 2.0.0.0 Playback: 2.0.0.4

Device Config: 2.0.0.4 Build Date: Jul 22 2011 15:25:20

Language English

Overwrite: Click it, and it will cover the old records when HDD is full

Length: Time length for 1 record file

Alarm Record Length: Time length for alarm record

Disk List: C, D, E, F

Log Maintenance: Alarm and Operation log keep days

Picture DIR: Picture storage location by snapshot


Record DIR: Record storage location by local recording

Sync time with PC: Adjusting device and PC in order to make both at the same time

Version Info: CMS's version (video, net, decoder, playback and device config)

Language: Choose language for CMS

5.2.2 Alarm setting



Device list: Choose 1 device to set alarms


Alarm Enable: Click it to make sure all alarm functions available

Alarm Prompt Sound: Select any alarm prompt sound which you like

Sound File Path: Browse and choose prompt sound


Auto Watch Warn: Choose it to add following channels by alarm activated

Note: Please go to choose alarm type firstly




5.3 Remote Config

Select a device first, then set its configurations, see below picture:




5.3.1 Record: Click Record to go into record interface

Set record length, period, type etc...see below picture:



5.3.2 Alarm: Click Alarm to go into alarm configuration.


Alarm activation configuration (motion detect, video blind, video loss and alarm in), see below picture.




5.3.3 System

Click System to go into system set interface.


General: Set system time, language, video standard, DVR No., auto logout and so on, see below picture.




Encode: Set DVR specifications of resolution, FPS, video quality etc...See below picture.




Network: Set IP address, port, DNS etc...in order to remote monitor by network and mobile, see below picture:




Net Service: Set IP filter, DDNS, Email etc...see below picture




CAM Name: Add or modify camera name by your need, see below picture



PTZ config: Set PTZ parameters to make sure the same as speed cameras.




RS232: Set RS232 port configurations, see below picture.




Advanced: Click Advanced to go into advanced interface.


HDD manage




Account: Modify User, group, password, add user, group etc...see below picture:




Auto Maintain: Set Auto-Reboot time and files management, see below picture



Default: Restore to factory settings



Info Click Info to go into system info interface, see below picture:




In system info, there are HDD info, LOG and Version.

Chapter 6 Account


6.1 Group

Add, delete group and set group right, see below picture:



6.2 User

Add, delete user and modify password



Chapter 7 Local Log

User can search operation log, alarm log and other logs by time, see below picture.

The screenshot shows a 'Local Log' window with a search interface and a table of log entries. The search interface includes dropdown menus for 'Log Type' (set to 'Operation') and 'Operation' (set to 'All'), and time selection fields for 'Begin Time' (2011- 7-25 0:00:00) and 'End Time' (2011- 7-25 23:59:59). Below the search fields are buttons for 'Search', 'NextPage', 'PrePage', and 'Log Export'.

No	Type	Date	Device	User	Describe
1	System Op...	2011-07-25 15:50:41		super	User:super Login
2	Video	2011-07-25 15:51:21	192.168.1.227	admin	Connect successful
3	System Op...	2011-07-25 15:51:26	192.168.1.227	admin	Disconnect
4	Video	2011-07-25 15:51:27	192.168.1.227	admin	Connect successful
5	Video	2011-07-25 15:51:29	192.168.1.227	admin	Channel 1 Open OK
6	Playback	2011-07-25 16:18:09	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
7	Playback	2011-07-25 16:18:12	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
8	Playback	2011-07-25 16:18:14	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
9	Playback	2011-07-25 16:18:15	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.45.00-1..
10	Playback	2011-07-25 16:18:17	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
11	Playback	2011-07-25 16:18:23	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
12	Playback	2011-07-25 16:18:24	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
13	Playback	2011-07-25 16:18:24	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
14	Playback	2011-07-25 16:18:25	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
15	Playback	2011-07-25 16:18:25	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
16	Playback	2011-07-25 16:18:25	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
17	Playback	2011-07-25 16:18:26	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
18	Playback	2011-07-25 16:18:26	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
19	Playback	2011-07-25 16:18:26	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
20	Playback	2011-07-25 16:18:26	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
21	Playback	2011-07-25 16:18:27	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
22	Playback	2011-07-25 16:18:27	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
23	Playback	2011-07-25 16:18:28	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
24	Playback	2011-07-25 16:18:28	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
25	Playback	2011-07-25 16:18:30	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/14.45.00-1..
26	Playback	2011-07-25 16:18:31	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/14.15.00-1..
27	Playback	2011-07-25 16:18:33	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/11.20.00-1..
28	Playback	2011-07-25 16:18:35	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
29	Playback	2011-07-25 16:18:35	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
30	Playback	2011-07-25 16:18:36	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.39.30-1..
31	Playback	2011-07-25 16:18:37	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.45.00-1..
32	Playback	2011-07-25 16:18:41	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.47.33-1..
33	Playback	2011-07-25 16:18:42	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.55.00-1..
34	Playback	2011-07-25 16:18:43	192.168.1.227	admin	Remote CAM1 /idea0/2011-07-25/001/10.55.00-1..

Chapter 8 Record


8.1 Playback

There are 2 playback modes---Remote playback and Local playback.

Remote playback: Playback at Device-side.

Local playback: Playback at Client-side.

User could playback record files of any times, max playback channels is 4.



Button instruction


No.	Button	Meanings
1		Play
2		Pause
3		Stop
4		Slow play
5		Fast play
6		Last frame
7		Next frame

8.2 Download & Backup

User could playback record files at set time and channels, select record files, click "Download/Backup" and select "save directory".


Note: Remote playback----Download

Local playback---Backup




8.3 Record plan

Set your record plan on any clocks and days, see below picture:




Edit Template, see below picture:



After set name, then click "add" and "OK"

Choose "channel" first, then go to set record time from Monday to Sunday.



Note: After set record plan, If it need to record, please make sure the below 3 points:


1. Choose disk for recording at Local config.
2. Make sure the device is connected to network.
3. Make sure local computer is always open.

Chapter 9 Advanced

It contains two options---Decoder and Map.


9.1 Decoder

It can manage and config remote decoder very easy, sees below picture:



9.1.1 Add decoder

Right-click to add decoder, see below picture:



Device Name: Name of decoder, it is set by yourself

Domain: Domain name of decoder


IP address: IP address of decoder

Port: TCP port, default is 34567

User Name: Login name of decoder, default is admin


Password: Password of decoder

After you add decoder successfully, it will come out a "decoder" icon in this interface, right-click this icon to edit, delete and set attribute.




9.1.2 Edit

Right-click decoder icon to "edit decoder", see below pictures:



9.1.3 Set decoder Attribute

Right click "Attribute", see below picture:



In the device list of left side, select 1 camera, then select 1 camera of right side, at last click "Add" in the center, for example:

See above picture,

Decoder CAM01 decode output for "home-CAM2"

Decoder CAM02 decode output for "bank-CAM1"

Decoder CAM03 decode output for "supermarket-CAM1"


Decoder CAM04 decoder output for "car park-CAM4"

Delete decoder


Right-click to delete decoder

9.2 E-MAP


E-MAP is a plan for simulating live screen, user can use it to add & delete cameras and set e-map alarm activation, see below picture:



1. Click "Edit" first at the left bottom, then click "Picture Edit", see below picture:




2. Click "Add" to add picture, see below picture:



3. After set picture name, description, picture path, then click "OK" back to main interface.

Click "Picture" and drag 1 picture to the right side, see below picture:



4. Click "Device" to drag device's channel to the map, then the channel name will appear at the map, double-click it to name and describe it.

Appendix A Abbreviations

Abbreviation	Full name	Chinese meaning
CMS	center manager system	网络视频控制中心
DVS	Digital Video System	数字视频监控系统
PTZ	Pan/Tilt/Zoom	云台设备
TCP/IP	Transmission Control Protocol / Internet Protocol	传输控制协议/互联网协议

Appendix B Main parameters

Video Compression		H.264 main profile	
Audio Compression		G711A	
Video Resolution		D1/HD1/CIF/QCIF	
Display resolution	Resolution	NTSC	704 x 480
		PAL	704x576
	Rate	NTSC	30FPS
		PAL	25FPS
Frame rate		30/25(NTSC/PAL) F/S	
Video input		BNC input	
Audio input		RCA input	
Type of compressed code		Combine code	
Rate of compressed code		32kbps ~ 2048kbps(adjustable)	
Network Protocol		TCP/IP, static IP , DHCP , PPPoE	
Net Interface		10/100M RJ45	
PTZ protocol		Pelco-P/ Pelco-D/ Minking/ Linlin/ Neon/ Star/ Vido etc...	
Remote Monitor		IE browse, CMS and Mobile	